


Owner's Manual & Installation Instructions Manuel d'utilisation et Instruction d'installation QFD15 Series/Séries/Serie

# Dryers Sécheuses



# **TABLE OF CONTENTS**

SAFETY INFORMATION	
USING THE DRYER	
	4
Loading	
Features	8
CARE AND CLEANING	9
INSTALLATION INSTRUCTIONS	11
Stacking (Optional)	24
Reversing The Door Swing (Optional)	26
TROUBLESHOOTING TIPS	28
LIMITED WARRANTY	31
CONSUMER SUPPORT	
RECORD KEEPING	
Thank you for purchasing this Haier Appliances product. This Owner's Manual will help you get the best performance from your new dryer.	Model number
For future reference, record the model and serial number located on a label on the front of the dryer behind the door.	Serial number
Staple your proof of purchase to this manual to aid in	
obtaining warranty service if needed.	Date of purchase

# SAFETY INFORMATION

# IMPORTANT SAFETY INFORMATION READ ALL INSTRUCTIONS BEFORE USING THE APPLIANCE

**▲WARNING** 

- To reduce the risk of fire, explosion, electric shock, or injury to persons when using your appliance, follow basic precautions, including the following:
- Read all instructions before using the appliance.
- DO NOT dry articles that have been previously cleaned in, washed in, soaked in, or spotted with gasoline, dry-cleaning solvents, or other flammable or explosive substances, as they give off vapors that could ignite or explode.
- DO NOT place items exposed to cooking oils in your dryer. Items contaminated with cooking oils may contribute to a chemical reaction that could cause a load to catch fire. To reduce the risk of fire due to contaminated loads, the final part of the tumble dryer cycle occurs without heat (cool down period). Avoid stopping a tumble dryer before the end of the drying cycle unless all items are quickly removed and spread out so that the heat is dissipated.
- DO NOT allow children to play on or in this appliance. Close supervision of children is necessary when this appliance is used near children.
- Before the appliance is removed from service or discarded, remove the door to the drying compartment.
- **DO NOT** reach into the appliance if the drum is moving.
- DO NOT install or store this appliance where it will be exposed to the weather.
- **DO NOT** tamper with controls.
- **DO NOT** climb or stand on this unit.
- DO NOT repair or replace any part of this appliance or attempt any servicing unless specifically recommended in the user-maintenance instructions or in published user-repair instructions that you understand and have the skills to carry out.
- Follow all fabric care instructions and warnings to prevent melting of garments or damage to the appliance.
- DO NOT use fabric softeners or products to eliminate static unless recommended by the manufacturer of the fabric softener or product.
- DO NOT dry articles containing foam rubber or similarly textured rubber-like materials.
- Clean lint screen before or after each load.
- **DO NOT** operate the dryer without the lint filter in place.
- DO NOT store combustible materials, gasoline or other flammable liquids near the dryer. Keep area around the exhaust opening and adjacent surrounding areas free from the accumulation of lint, dust and dirt.
- The interior of the appliance and exhaust duct should be cleaned periodically by qualified service personnel.
- Unplug the appliance or turn off the circuit breaker before servicing. Pressing the **Power** ((b)) or **Start/Pause** ((b)/(b)) button **DOES NOT** disconnect power.
- DO NOT operate this appliance if it is damaged, malfunctioning, partially disassembled, or has missing or broken parts, including a damaged cord or plug.
- DO NOT spray any type of aerosol into, on or near dryer at any time. DO NOT use any type of spray cleaner when cleaning dryer interior. Hazardous fumes or electrical shock could occur.
- See "ELECTRICAL CONNECTION" located in the Installation Instructions for grounding instructions.

**▲**WARNING

To reduce the risk of fire, electric shock, or injury to persons, read the IMPORTANT SAFETY INFORMATION before operating this appliance.

Throughout this manual, features and appearance may vary from your model.



Loosely add items.

 Close door.
 NOTE: Dryer will not start with door open.

# Step 2\*

 If the screen is dark, press and hold the power button for 2 seconds to "wake up" the display.




 Select a dry cycle. (Defaults are set for each dry cycle. These default settings can be changed. See control settings for more information.) Step 4\*



 Press and hold the start button for 1 second.

\*Instructions can also be found by touching the document ( ) icon, on the cycle selection screen, in the top right corner.



# **Display and Status Lights**

The display shows the approximate time remaining until the end of the cycle.

In addition, this display will show the dryer status:

Status	Dry → Damp → Cool		
•	Controls lock feature.		
Clean Filter	Time to clean the filter. See the <b>Care and Cleaning</b> section.		
Damp Alert	When <b>Damp Alert</b> option is selected and clothes have dried to a damp dryness level, indicator will appear and dryer will beep.		
Estimated Time Remaining	Display shows the estimated time remaining until set cycle is completed.		
Ext Tumble	Indicates the Extended Tumble feature is set.		
Delay	Indicates <b>Delay Dry</b> set time is selected.		
Low Air	Indicates decrease in performance of the dryer and increase risk of lint accumulation in the ducts and dryer.		
*	Indicates the <b>My Cycle</b> feature is set.		
eDry	Shows <b>eDry</b> setting selected.		
Temp	Shows <b>High</b> , <b>Medium</b> , <b>Low</b> or <b>No Heat</b> temperature setting selected.		
Level	Shows Extra Dry, Dry or Damp dryness setting selected.		
Delay Dry	Indicates <b>Delay Dry</b> is set time is selected.		

# Α

### **Power**

Press and hold for 2 seconds to "wake up" the display. If the display is active, press and hold for 2 seconds to turn the dryer off. **NOTE:** Pressing the power does not disconnect the appliance from the power supply.

# В

### **Dry Cycles**

The dry cycle controls the cycle time for the drying process. The chart below will help you match the dry setting with the loads.

Mixed Loads	For loads consisting of cottons and poly blends.		
Cottons	For cottons and most linens. <b>NOTE:</b> ENERGY STAR® models are tested on Cottons with default settings.		
Heavy duty	For large coats, bed spreads, mattress covers, sleeping bags, blankets, comforters, jackets, small rugs and similar large and bulky items.		
Towels	Use for towels OR sheets. It is not recommended to mix towels and sheets in the same load.		
Casuals	For wrinkle-free, permanent press and delicate items, and knits.		
Active Wear	Clothing worn for active sports exercise and some casual wear. Fabrics include new technology finishes and stretch fibers such as Spandex. Also for clothing labeled Easy Care or Perma Press: For wrinkle-free and permanent press items.		
Sanitize	Reduces certain types of bacteria by 99.6%, including: Staphylococcus aureus and Pseudomonas aeruginosa. The antibacterial process occurs when high heat is used during a portion of this drying cycle.		
Quick Dry	For small loads that are needed in a hurry, such as sports or school uniforms. Can also be used if the previous cycle left some items damp, such as collars or waistbands.		
Delicates	For lingerie and special-care fabrics.		
Dewrinkle	For removing wrinkles from items that are dry or slightly damp. This cycle is not recommended for delicate fabrics.		
Warm Up	Provides 25 minutes of warming time to warm up clothes.		
Air Fluff	Provides 30 minutes of tumbling time without heat.		
Rack Dry	For drying delicate items without tumbling, use drying rack accessory. Place items flat on the drying rack such as wool sweaters and delicate fabrics. Dry with low heat.		
Baby Care	For drying children's clothes and other small items.		
Jeans	For drying denim and heavy canvas textiles.		
Timed Dry	Use to set your own dry time. Time Dry is also recommended for small loads. To use:  1. Select Timed Dry cycle.  2. Select the drying Time in 10-minute increments up to 2 hours and 30 minutes.  2. Select the dry Temp.  3. Close the door.  4. Press and hold Start.		



### 1



### Temp (Temperature)

You can change the temperature of your dry cycle.

High	For regular to heavy cottons.		
Medium	For synthetics, blends and items labeled Permanent Press.		
Low	For delicates, synthetics and items labeled Tumble Dry Low.		
No Heat	This option may only be used with <b>Air Fluff</b> and <b>Timed Dry</b> , in which items are tumbled without heat.		





#### Level

The sensor continuously monitors the amount of moisture in the load. When the moisture in your clothes reaches your selected dry level, the dryer will stop.

NOTE: Sensor dry Level can be used with all cycles except Timed Dry, Air Fluff, Rack Dry, Warm Up and Dewrinkle.

Extra Dry	Ory Use for heavy-duty fabrics or items that should be very dry, such as towels.	
Dry	Use for normal dryness level suitable for most loads. This is the preferred cycle for energy saving.	
Less Dry	Use for lighter fabric (ideal for ironing).	
Damp	For leaving items partially damp.	





### **Delay Dry**

Use to delay the start of your dryer.

- 1. Choose your dry cycle and any options.
- 2. In the **Delay Dry** section. You can change the delay time in 1 hour increments up to 24 hours.
- 3. Press and hold the start () icon for 1 second to start the countdown. The selected delay time will not be shown on the screen. Only the estimated cycle time will be visible. Once the delayed time period has been completed, the selected dry cycle will start.

**NOTE:** If the door is opened while the dryer is in **Delay Dry**, the countdown time will not restart unless the door is closed and **Start** icon has been pressed again.





### **Options**

### **Damp Alert**

This option causes the dryer to beep when clothes have dried to a damp level and the **Damp Alert** indicator to appear on the screen. Remove items that you wish to hang dry. This feature will only beep when the **Damp Alert** option is selected. The dryer will continue to dry after the **Damp Alert** indicator is populated on the screen and dryer beeps. Removing clothes and hanging them when they are damp can reduce the need to iron some items.

#### **Extended Tumble**

Minimizes wrinkles by adding approximately 2 hours of no-heat tumbling after clothes are dry.

The estimated time remaining display will show "END".

The extended tumble time does not get added to the cycle time on the display.

### **Detangle**

Activates alternating forward and reverse tumbling to reduce tangling, dry more evenly, and improve drying times. Typical loads such as bed and bath mixed loads, where sheets, towels and pillow cases are laundered together, benefit from this capability. When the dryer reverses direction, there will be a slight pause and sound change. This is normal.

NOTE: Detangle is selected by default for Towels and Heavy Duty cycles.

#### **eDry**

Reduces total energy consumption of specific dryer cycles by adjusting certain heat settings.

NOTE: Cycle times will change when eDry is selected.

**ENERGY STAR®** models are tested on **Cottons** cycle with default settings to determine energy use rating of this dryer. The **eDry** option will default to on for **Cottons**. Temperature settings on High and dryness level setting on Dry are specifically designed for this cycle to reduce energy consumption. For optimal energy savings, turn **eDry** on. For optimal drying times, turn **eDry** off. Energy savings will vary across loads and cycles.

The eDry selection can be used with Mixed Loads, Cottons, Heavy Duty, Towels, Casuals, Active Wear and Delicates.



### My Cycle

Set up your favorite combination of settings for each cycle and save them here for one touch recall. These custom settings can be set while a cycle is in progress. **NOTE:** you can store one **My Cycle** combination of settings for each cycle.

### To store a My Cycle combination of settings:


- 1. Select your drying cycle.
- 2. Change **Temp** and **Level** settings to fit your needs.
- 3. Select any drying options you want.
- 4. Press and hold the ☆ pad for 3 seconds to store your selection. A beep will sound and the icon will light up.

### To recall your stored My Cycle combination:

Select the cycle and press the  $\Rightarrow$  icon before drying a load.

### To change your stored My Cycle combination:

Repeat steps 1-4.



### Lock

You can lock the controls to prevent any selections from being made. Or you can lock or unlock the controls after you have started a cycle.


Children cannot accidentally start the dryer by touching pads with this option selected.

To lock the dryer, press and hold the lock ( ) pad in the top right corner for 3 seconds and a lock screen will appear.

To unlock the dryer controls, press and hold the unlock ( ) pad for 3 seconds and the lock screen will disappear.

The control lock icon on the display will light up when it is on.

**NOTE:** The **Power** button can still be used when the machine is locked.



WiFi Connect

EXIT

On Off



Select the gear symbol (3) in the top right corner to enter the **Settings** screen.

When the control panel is powered on, the dryer will beep at the end of the cycle and every time you press a button on the control panel.

Use the **Option** pad to select either High, Med, Low, or Off.

**NOTE:** The selected volume is for both end of cycle and pad sounds.

### Language

Use the **Option** pad to select either English, Spanish, or French.

#### **Briahtness**

To change the brightness of the screen, use the brightness slider to change from darker to brighter.

### WiFi Connect + Tub Light

Use the WiFi Connect + Tub Light togale button to turn this feature on or off. Togaling this feature on will enable the WiFi Connect function and enable the usage of the tub light when the door is opened & closed. Follow the directions on the Wifi Connect screen using the information provided to connect with the GEA Laundry App. Toggling this feature off will disable the Wifi Connect function and disable the tub light.

NOTE: When the dryer to set up with the GEA Laundry App, new software may be available to install. After approving the installation of the new software through the GEA Laundry App, the dryer tub light will flash on and off during the software installation. The dryer tub light will stop flashing and turn off after the software is done installing.



#### Start/Pause

Start - Press and hold for 1 second to start or restart a cycle.

Pause - If the dryer is running, press and hold for 1 second to pause the cycle. This function can be used to add garments during a cycle.

NOTE: If the dryer is paused and the cycle is not restarted within 15 minutes, the current cycle will be cancelled.






# LOADING

Always follow fabric manufacturer's care label when laundering.

### **Fabric Care Labels**

Below are fabric care label "symbols" that affect the clothing you will be laundering.

### **Dry Labels**



### **Sorting and Loading Hints**

# AWARNING / Fire Hazard

- Keep flammable materials and vapors, such as gasoline, away from dryer.
- **DO NOT** dry anything that has ever had anything flammable on it (even after washing).
- No washer can completely remove oil.

- **DO NOT** dry anything that has ever had any type of oil on it (including cooking oils).
- Items containing foam, rubber, or plastic must be dried on a clothesline.
- Failure to do so can result in death, explosion, or fire.

As a general rule, if clothes are sorted properly for the washer, they are sorted properly for the dryer. Try also to sort items according to size. For example, do not dry a sheet with socks or other small items.

Do not add fabric softener sheets once the load has become warm. They may cause fabric softener stains. Bounce® Fabric Conditioner Dryer Sheets have been approved for use in this dryer when used in accordance with the manufacturer's instructions.

Do not overload. This wastes energy and causes wrinkling.

### **Drying Rack**

A handy drying rack may be used for drying delicate items such as washable sweaters. Place items flat on the drying rack and block such items as wool sweaters and delicate fabrics. Dry with low heat.

To install the drying rack, extend the drying rack into the dryer drum and rest the front two legs on the front angled ledge.

#### **NOTES:**

- The drying rack is designed for use with the **Timed Dry** cycle. Use with sensor cycles may result in damp items or extended cycle times.
- Do not use this drying rack when there are other clothes in the dryer, that are not placed on the rack.
- The drying rack, **WE01X26416**, is available as an accessory. Visit our website at **haierappliances.com/parts** or in Canada visit **haiercanada.ca/parts**.

visit **haiercanada.ca/parts**.



# **CARE AND CLEANING**

### Interior and Duct

The interior of the appliance and exhaust duct should be cleaned once a year by qualified service personnel.

**The Exhaust Duct:** Inspect and clean the exhaust ducting at least once a year to prevent clogging. A partially clogged exhaust can lengthen the drying time.

**The Exhaust Hood:** Check with a mirror that the inside flaps of the hood move freely when operating. Make sure that there is no wildlife (birds, insects, etc.) nesting inside the duct or hood.

#### **Exterior**

Wipe or dust any spills or washing compounds with a damp cloth. Dryer control panel and finishes may be damaged by some laundry pretreatment soil and stain remover products. Apply these products away from the dryer. The fabric may then be washed and dried normally. Damage to your dryer caused by these products is not covered by your warranty.

### **Lint Filter**

Clean the lint filter before each use.

Pull out the lint filter. Moisten your fingers and remove the captured lint. Once clean, slide the filter back into position. Have a qualified technician vacuum the lint from the dryer once a year.



NEVER OPERATE THE DRYER WITHOUT ITS FILTER IN PLACE.

#### Stainless Steel

To clean stainless steel surfaces use a damp cloth with a mild, non-abrasive cleaner suitable for stainless steel surfaces. Remove the cleaner residue and then dry with a clean cloth.

The stainless steel used to make the dryer drum provides the highest reliability available in a Haier Appliances dryer. If the dryer drum should be scratched or dented during normal use, the drum will not rust or corrode. These surface blemishes will not affect the function or durability of the drum.

# **CARE AND CLEANING**

### **Drum Lamp**

**NOTE:** The drum lamp is not consumer replaceable on models where there is a flat cover over an LED bulb. If this light should ever stop working, contact us for service.

### For models that have a domed cover over the bulb secured by a screw:

Before replacing the light bulb, be sure to unplug the dryer power cord or disconnect the dryer at the household distribution panel by removing the fuse or switching off the circuit breaker. Reach above dryer opening from inside the drum to locate the light.

Remove the screw and the plastic cover to access the bulb. Replace with the appropriate bulb and then reaffix the cover and screw.

Order replacement bulb **WE11X26351** by visiting our website at **haierappliances.com/parts** or in Canada visit **haiercanada.ca/parts**. You may also purchase appliance bulb **7C7** from your local retailer.

When the door is opened, the drum lamp automatically turns on and remains on for 2 minutes. When the door is closed, the drum lamp will remain on for 30 seconds.

# ▲WARNING 🕍 - Electrical Shock Hazard

Disconnect power supply before servicing.

Replace all parts and panels before operating.
Failure to do so can result in death or electrical shock.

# DRYER

If you have questions, visit our website at haierappliances.com or in Canada visit haiercanada.ca.

# **BEFORE YOU BEGIN**

Read these instructions completely and carefully.

- IMPORTANT Save these instructions for local electrical inspector's use.
- **IMPORTANT** Observe all governing codes and ordinances.
- Install the clothes dryer according to the manufacturer's instructions and local codes.
- Note to Installer Be sure to leave these instructions with the Consumer.
- Note to Consumer Keep these instructions for future reference.
- Clothes dryer installation must be performed by a qualified installer.
- This dryer must be exhausted to the outdoors.
- Before the old dryer is removed from service or discarded, remove the dryer door.
- Service information and the wiring diagram are located in the control console.
- Do not allow children on or in the appliance. Close supervision of children is necessary when the appliance is used near children.
- Proper installation is the responsibility of the installer.
- Product failure due to improper installation is not covered under the Warranty.
- Install the dryer where the temperature is above 50°F for satisfactory operation of the dryer control system.
- Remove and discard existing plastic or metal foil duct and replace with UL-listed duct.

# **AWARNING**

- Risk of Fire
- Clothes dryer installation must be performed by a qualified installer.
- Install the clothes dryer according to these instructions and local codes.
- DO NOT install a clothes dryer with flexible plastic venting materials. If flexible metal (semi-rigid or foil-type) duct is installed, it must be UL-listed and installed in accordance with the instructions found in "Connecting the Dryer to House Vent" later in this manual. Flexible venting materials are known to collapse, be easily crushed and trap lint. These conditions will obstruct dryer airflow and increase the risk of fire.
- **DO NOT** install or store this appliance in any location where it could be exposed to water or weather.
- To reduce the risk of severe injury or death, follow all installation instructions.
- Save these instructions. (Installers: Be sure to leave these instructions with the customer.)

If you are planning to stack the washer and dryer, order Stacking Kit number **GFA24KITL** to be used for this dryer. Kit sold separately.


Visit our website at haierappliances.com/parts or in Canada visit haiercanada.ca/parts.


### **UNPACKING YOUR DRYER**

Tilt the dryer sideways and remove the foam shipping pads by pulling at the sides ar breaking them away from the dryer legs. Be sure to remove all of the foam pieces ar the legs.









### **POWER CORDS**

Haier Appliances strongly recommends the use of factory specified parts. Select the power cord to fit your installation requirements.

Part Number	Туре	Length	Amperage
WX9X2	3-Prong	4 Feet	30
WX9X3	3-Prong	5 Feet	30
WX9X4	3-Prong	6 Feet	30
WX9X18	4-Prong	4 Feet	30
WX9X19	4-Prong	5 Feet	30
WX9X20	4-Prong	6 Feet	30

Visit our website at **haierappliances.com/parts** or in Canada visit **haiercanada.ca/parts**.

### **ACCESSORIES:**

Visit our website at haierappliances.com/parts or in Canada visit haiercanada.ca/parts.

Part Number	Accessory	
PM08X10085	Flexible Metal Dryer Transition Duct	

12

### REQUIREMENTS FOR ALCOVE OR **CLOSET INSTALLATION**



Keep flammable materials and vapors, such as gasoline, away from dryer.

Place dryer at least 18" (46 cm) above the floor for a garage installation.

Failure to do so can result in death, explosion, or fire.

- The dryer MUST be vented to the outdoors.
- · Minimum clearance between dryer cabinet and adjacent walls or other surfaces is:

0" either side

1" front and rear

1" top

- The rear of the dryer should face a wall.
- Consideration must be given to provide adequate clearance for installation and service.
- Closet doors must be louvered or otherwise ventilated and have at least 60 square inches of open area. If the closet contains both a washer and a dryer, doors must contain a minimum of 120 square inches of open area.

**NOTE:** WHEN THE EXHAUST DUCT IS LOCATED AT THE REAR OF THE DRYER, THE CONFIGURATION OF THE DUCTING MAY REQUIRE GREATER THAN 3" OF REAR CLEARANCE.

### MINIMUM CLEARANCE OTHER THAN ALCOVE OR CLOSET INSTALLATION

Minimum clearance to combustible surfaces and for air opening are: 0" both sides, 1" rear and 1" top.

The rear of the dryer should face a wall.

Consideration must be given to provide adequate clearance for installation and service.

### MOBILE OR MANUFACTURED HOME **INSTALLATION**

- Installation MUST conform to the MANUFACTURED HOME CONSTRUCTION AND SAFETY STANDARD. TITLE 24. PART 3280 or STANDARD FOR MOBILE HOMES CAN/CSA-Z240 MH, or, when such standards are not applicable, with AMERICAN NATIONAL STANDARD FOR MOBILE HOME, ANSI/ NFPA NO. 501B.
- The dryer MUST be vented to the outdoors.
- The exhaust vent MUST be securely fastened to a non-combustible portion of the mobile home.
- The vent MUST NOT be terminated beneath a mobile or manufactured home.
- · The vent duct material MUST BE METAL.
- KIT 14-D346-33 MUST be used to attach the dryer securely to the structure.
- The vent MUST NOT be connected to any other duct, vent or chimney.
- DO NOT use sheet metal screws or other fastening devices which extend into the interior of the exhaust vent.
- Provide an opening with a free area of at least 25 square inches for introduction of outside air into the drver room.
- See the sections for electrical connection information.

### **UNDERCOUNTER INSTALLATION**

If an undercounter installation is desired:

- · No special dryer installation kit is required.
- If the dryer is installed alone, a minimum of 60 square inches of open area is required. If a washer and dryer are installed together, a minimum of 120 square inches of open area is required.

# Countertop and side cabinets 60 square inches min. open area



# BATHROOM OR BEDROOM INSTALLATION

The installation must conform with local codes or, in the absence of local codes, with the NATIONAL ELECTRICAL CODE, ANSI/NFPA NO. 70 (for electric dryers).

14

# **CONNECTING AN ELECTRIC DRYER**

### **TOOLS YOU WILL NEED**

■ Slip-joint pliers



■ Flat-blade screwdriver



■ Phillips screwdriver



Level



### **MATERIALS YOU WILL NEED**

■ 4" dia. metal elbow



■ 3/4" Strain relief (UL recognized)



■ 4" Duct clamps (2) or 4" spring clamps (2)





■ Safety glasses



■ 4" dia. metal duct (recommended)



■ 4" dia.. UL-listed flexible metal duct (if needed)



■ 4" Cover Plate (Kit WE49X22606) (if needed)



■ Gloves



■ Exhaust hood



Duct tape




■ Dryer power cord kit (not provided with dryer)

UL rated 120/240V, 30A with 3 or 4 prongs. Identify the plug type as per the house receptacle before purchasing line cord.



Stacking installations may require a power cord up to 6 feet in length.

Before making the electrical connection, turn off the circuit breaker(s) or remove the dryer's circuit fuse(s) at the electrical box. Be sure the dryer cord is unplugged from the wall. NEVER LEAVE THE ACCESS COVER OFF THE TERMINAL BLOCK.





Disconnect power supply before servicing. Replace all parts and panels before operating. Failure to do so can result in death or electrical shock.

### **ELECTRICAL CONNECTION** INFORMATION FOR ELECTRIC **DRYERS**

For electrical connections using a power cord:

### **AWARNING**



- Fire Hazard

Use a new UL-listed 240V 30 amp dryer power supply cord with closed ring terminals or spade terminals with upturned ends.

Use a UL-listed strain relief.

Disconnect power before making electrical connections.

Connect neutral wire (white or center wire) to center terminal.

Ground wire (green or bare wire) must be connected to green ground connector.

Connect remaining two supply wires to remaining two

Securely tighten all electrical connections.

Replace the terminal block cover.

Failure to do so can result in death, fire or electrical shock.

### GROUNDING INSTRUCTIONS

For a grounded, cord-connected dryer: This dryer must be grounded. In the event of a malfunction or breakdown, grounding will reduce the risk of electric shock by providing a path of least resistance for electric current. This dryer uses a cord having an equipmentgrounding conductor and a grounding plug. The plug must be plugged into an appropriate outlet that is properly installed and grounded in accordance with all local codes and ordinances.

**▲WARNING** Improper connection of the equipment-grounding conductor can

result in a risk of electric shock. Check with a qualified electrician, or service representative or personnel, if you are in doubt as to whether the appliance is properly grounded. **DO NOT** modify the plug on the power supply cord. If it will not fit the outlet, have a proper outlet installed by a qualified electrician.

SAVE THESE INSTRUCTIONS



# **▲WARNING** → Electrical Shock Hazard

TO PREVENT ELECTRIC SHOCK, DISCONNECT POWER BEFORE SERVICING.

This dryer should be connected to an individual branch circuit with 10 gauge copper wire minimum through a 30 amp fuse or circuit breaker. **DO NOT** fuse neutral.

Use copper conductors only.

### **ELECTRICAL CONNECTION** INFORMATION FOR ELECTRIC **DRYERS**

For direct wire connections:

# **AWARNING** Fire Hazard



Use 10 gauge copper wire.

Use a UL-listed strain relief.

Disconnect power before making electrical connections.

Connect neutral wire (white or center wire) to center terminal.

Ground wire (green or bare wire) must be connected to green ground connector.

Connect remaining two supply wires to remaining two terminals.

Securely tighten all electrical connections.

Replace the terminal block cover.

Failure to do so can result in death, fire or electrical shock.

### **GROUNDING INSTRUCTIONS**

For a permanently connected dryer: This dryer must be connected to a grounded metal, permanent wiring system, or an equipment-grounding conductor must be run with the circuit conductors and connected to the equipment-grounding terminal on the appliance.

Improper connection of the equipment-grounding

**AWARNING** conductor can result in a risk of electric shock. Check with a qualified

electrician, or service representative or personnel, if you are in doubt as to whether the appliance is properly arounded.

SAVE THESE INSTRUCTIONS



### **▲WARNING** → Electrical Shock Hazard


TO PREVENT ELECTRIC SHOCK, DISCONNECT POWER BEFORE SERVICING.

This dryer should be connected to an individual branch circuit with 10 gauge copper wire minimum through a 30 amp fuse or circuit breaker. **DO NOT** fuse neutral.

Use copper conductors only.

# CONNECTING DRYER USING 4-WIRE CONNECTION (MUST BE USED FOR MOBILE HOME INSTALLATION)

**NOTE:** Since January 1, 1996, the National Electrical Code requires that new constructions use a 4-wire connection to an electric dryer. A 4-wire cord must also be used where local codes do not permit grounding through the neutral. 3-wire connection is NOT for use on new construction.




4 #10 AWG minimum copper conductors or 120/240V 30A power supply cord kit marked for use with dryers and provided with closed loop or spade terminals with upturned ends (not supplied).

- **1.** Turn off the circuit breaker(s) (30 amp) or remove the dryer's circuit fuse at the electrical box.
- **2.** Be sure the dryer cord is unplugged from the wall receptacle.
- **3.** Remove the power cord cover located at the upper back.
- **4.** Remove green ground screw and retain for use in Step 7. Remove center screw (marked N) in terminal block. Remove and discard ground strap.
- **5.** Install 3/4 in. UL-recognized strain relief to power cord entry hole. Bring power cord through strain relief and bracket.
- **6.** Connect power cord as follows:
  - A. Connect the 2 hot lines to the outer screws of the terminal block (marked L1 and L2).
  - **B.** Connect the neutral (white) line to the center of the terminal block (marked N).
- 7. Attach ground wire of power cord with the green ground screw (hole above strain relief bracket). Tighten all terminal block screws (3) securely.
- 8. Properly secure power cord to strain relief and bracket.
- 9. Reinstall the cover.

# NEVER LEAVE THE COVER OFF OF THE TERMINAL BLOCK.

# CONNECTING DRYER USING 3-WIRE CONNECTION

If required, by local code, install external ground (not provided) to grounded metal, cold water pipe, or other established ground determined by a qualified electrician.



3 #10 AWG minimum copper conductors or 120/240V 30A power supply cord kit marked for use with dryers and provided with closed loop or spade terminals with upturned ends (not supplied).

### **3-wire Connection**

Not for use in Canada.

DO NOT use for Mobile Home Installations.

NOT for use on new construction.

NOT for use on recreational vehicles.

NOT for use in areas where local codes prohibit grounding through the neutral conduction.

- **1.** Turn off the circuit breaker(s) (30 amp) or remove the dryer's circuit fuse at the electrical box.
- 2. Be sure the dryer cord is unplugged from the wall receptacle.
- **3.** Remove the power cord cover located at the upper
- **4.** Install 3/4-in. UL-recognized strain relief to power cord entry hole. Bring power cord through strain relief and bracket.
- 5. Connect power cord as follows:
  - **A.** Connect the 2 hot lines to the outer screws of the terminal block (marked L1 and L2).
  - **B.** Connect the neutral (white) line to the center of the terminal block (marked N).
- **6**. Be sure ground strap is connected to green ground screw on cabinet rear. Tighten all terminal block screws (3) securely.
- Properly secure power cord to strain relief and bracket.
- 8. Reinstall the cover.

NEVER LEAVE THE COVER OFF OF THE TERMINAL BLOCK.

### **EXHAUSTING THE DRYER**

### **AWARNING**



### 💪 - Fire Hazard

This dryer MUST be vented to the outdoors.

Use only 4" rigid metal ducting for the home exhaust duct.

Use only 4" rigid metal, UL-listed flexible metal, or UL-listed metal foil dryer transition duct to connect the dryer to the home exhaust.

**DO NOT** use any plastic to vent the dryer, this includes the home exhaust duct, dryer transition duct, or within the dryer.

**DO NOT** use flexible metal or metal foil ducting for a home exhaust duct or within the dryer.

**DO NOT** exhaust into a chimney, kitchen exhaust, gas vent, wall, ceiling, attic, crawl space, or concealed space of a building.


**DO NOT** install a screen in or over the exhaust duct.


**DO NOT** install a booster fan in the exhaust duct. **DO NOT** use duct longer than specified in the exhaust length table.

Failure to follow these instructions can result in death or fire.

# TOOLS AND MATERIALS YOU WILL NEED TO INSTALL EXHAUST DUCT

Phillips-head screwdriver








duct clamp



■ Hacksaw









# VISIT HAIERAPPLIANCES.COM/PARTS OR IN CANADA VISIT HAIERCANADA.CA/PARTS

PM8X85 Outdoor exhaust hood

PM08X10085 8' Flexible metal clothes dryer transition

duct with 2 clamps

WX08X10130 4" Dryer exhaust clamp

WE49X22606 Rear exhaust opening cover, for side or

bottom vented dryers

# CONNECTING THE DRYER TO HOUSE VENT

#### **RIGID METAL TRANSITION DUCT**

- For best drying performance, a rigid metal transition duct is recommended.
- Rigid metal transition ducts reduce the risk of crushing and kinking.

# UL-LISTED FLEXIBLE METAL CLOTHES DRYER TRANSITION DUCT


- If rigid metal cannot be used, then UL-listed flexible metal clothes dryer transition duct (Haier Appliances part – PM08X10085) can be used.
- Never install transition duct in walls, ceilings, floors or other enclosed spaces.
- Total length of transition duct should not exceed 8'
   (2 4 m)
- For many applications, installing elbows at both the dryer and the wall is highly recommended (see illustrations in next section). Elbows allow the dryer to sit close to the wall without kinking and/or crushing the transition duct, maximizing drying performance.
- · Avoid resting the duct on sharp objects.

# UL-LISTED FLEXIBLE METAL (FOIL-TYPE) TRANSITION DUCT


- In special installations, it may be necessary to connect the dryer to the home exhaust vent using flexible metal (foil-type) transition duct. UL-LISTED universal flexible dryer transition duct (Haier Appliances parts – PM8X73 or WX8X73) may be used ONLY in installations where rigid metal or flexible metal transition ducting cannot be used AND where a 4" diameter can be maintained throughout the entire length of the transition duct.
- In Canada and the United States, only transition ducts that comply with "UL 2158A STANDARD FOR CLOTHES DRYER TRANSITION DUCT" shall be used.
- · Avoid resting the duct on sharp objects.
- For best drying performance:
  - 1. Slide one end of the duct over the clothes dryer outlet pipe.
  - 2. Secure the duct with a clamp.
  - 3. With the dryer in its permanent position, extend the duct to its full length. Allow 2" of duct to overlap the exhaust pipe. Cut off and remove excess duct. Keep the duct as straight as possible for maximum airflow.
  - 4. Secure the duct to the exhaust pipe with the other clamp.

18 49-3000195

# **EXHAUSTING THE DRYER (cont.)**



 DO cut duct as short as possible and install straight into wall.





 DO NOT bend or collapse ducting. Use elbows if turns are necessary.



• DO NOT use excessive exhaust length. Cut duct as short as possible.



• DO NOT crush duct against the wall.



• DO NOT set dryer on duct.

### **EXHAUST LENGTH**

Using exhaust longer than specified length will:

- Increase the drying times and the energy cost.
- · Reduce the dryer life.
- Accumulate lint, creating a potential fire hazard.

# The correct exhaust installation is **YOUR** RESPONSIBILITY.

Problems due to incorrect installation are not covered by the warranty.

The MAXIMUM ALLOWABLE length of the exhaust system depends upon the type of duct, number of turns, the type of exhaust hood (wall cap) and all conditions noted on the chart.

- Internal elbows added for side or bottom vent conversions must be included in the total elbow count.
- Any elbow greater than 45° should be treated as a 90° elbow; one elbow of 45° or less may be ignored.
- Two 45° elbows will be treated like one 90° elbow.
- For the side exhaust installations, add one 90° elbow to the chart.
- For every additional 90° elbow, reduce the allowable vent system length by 10 feet.
- When calculating the total vent system length, you must add all the straight portions and elbows of the system (including the transition duct).

# EXHAUST LENGTH

No. of 90° Elbows

2

	RECOMMENDED MAXIMUM LENGTH		
	Exhaust Hood Types		
	Recommended	Use only for short run installations	
	4" DIA 4"	A" DIA.	
	Rigid Metal	Rigid Metal	
	90 Feet	60 Feet	
	60 Feet	45 Feet	
	45 Feet	35 Feet	
	35 Feet	25 Feet	
П	25 Foot	15 Foot	

# **EXHAUSTING THE DRYER (cont.)**

### **EXHAUST SYSTEM CHECKLIST**

### **HOOD OR WALL CAP**

- Terminate in a manner to prevent back drafts or entry of birds or other wildlife.
- Termination should present minimal resistance to the exhaust airflow and should require little or no maintenance to prevent clogging.
- Wall caps must be installed at least 12" above ground level or any other obstruction with the opening pointed down.

#### **SEPARATION OF TURNS**

For best performance, separate all turns by at least 4
ft. of straight duct, including distance between last
turn and dampened exhaust hood (wall cap).

#### **SEALING OF JOINTS**


- All joints should be tight to avoid leaks. The male end of each section of duct must point away from the dryer.
- Duct joints should be made air- and moisture-tight by wrapping the overlapped joints with duct tape or aluminum tape.
- Do not assemble ductwork with any fasteners that extend into the duct. These fasteners can accumulate lint, creating a potential fire hazard.
- Horizontal runs should slope down towards the outdoors 1/4" per foot.
- Provide an access for inspection and cleaning of the exhaust system, especially at turns and joints.
   Exhaust system shall be inspected and cleaned at least once a year.

### **INSULATION**

 Ductwork that runs through an unheated area or is near air conditioning should be insulated to reduce condensation and lint build-up.

### **BEFORE YOU BEGIN**


- Remove and discard existing plastic or metal foil duct and replace with UL-listed duct.
- Remove any lint from the wall exhaust opening.



### STANDARD REAR EXHAUST


We recommend that you install your dryer before installing your washer. This will permit direct access for easier exhaust connection.

Slide the end of the exhaust duct on the back of the dryer and secure with duct tape or a hose clamp.




**NOTE:** We strongly recommend using rigid metal exhaust duct. However, if flexible ducting is used it must be UL-Listed metal, not plastic.

 For straight line installation, connect the dryer exhaust to the external exhaust hood using duct tape or clamp.



# RECOMMENDED CONFIGURATION TO MINIMIZE EXHAUST BLOCKAGE

Using duct elbows will prevent duct kinking and collapsing.



20

# **EXHAUSTING THE DRYER (cont.)**

### SIDE OR BOTTOM VENTING




Disconnect dryer from electrical supply.

Wear gloves and arm guards.

Close the back opening with cover plate (Kit WE49X22606).


Failure to do so may result in fire, electrical shock or lacerations.




Detach and remove the right, left or bottom knockout as desired. Remove the screw inside the dryer exhaust duct and save.

Pull the duct out of the dryer.

Cut the duct as shown and keep portion A.




# SIDE OR BOTTOM VENTING (cont.) ADDING A NEW DUCT



Reconnect the cut portion (A) of the duct to the blower housing. Make sure that the shortened duct is aligned with the tab in the base. Use the screw saved previously to secure the duct in place through the tab on the appliance base.

# ADDING ELBOW AND DUCT FOR EXHAUST TO RIGHT OR LEFT SIDE OF CABINET



- Preassemble 4" elbow with 4" duct. Wrap duct tape around joint.
- Insert duct assembly, elbow first, through the side opening and connect the elbow to the dryer internal duct.


Be sure not to pull or damage the electrical wires inside the dryer when inserting the duct.

# **EXHAUSTING THE DRYER (cont.)**

### SIDE OR BOTTOM VENTING (cont.)

# ADDING ELBOW AND DUCT FOR EXHAUST TO LEFT OR RIGHT SIDE OF CABINET (cont.)


 Apply duct tape as shown on the joint between the dryer internal duct and the elbow, and also the joint between the elbow and the side duct.



Use 4" rigid metal ducting only inside the dryer. Internal duct joints must be secured with tape, otherwise they may separate and cause a safety hazard.


# ADDING ELBOW FOR EXHAUST THROUGH BOTTOM OF CABINET

- Insert the elbow through the rear opening and connect it to the dryer internal duct.
- Apply duct tape as shown on the joint between the dryer internal duct and the elbow, and also the joint between the elbow and the bottom duct.



Internal duct joints must be secured with tape; otherwise, they may separate and cause a safety hazard.

# SIDE OR BOTTOM VENTING (cont.) ADDING COVER PLATE TO REAR OF



Connect standard metal elbows and ducts to complete the exhaust system. Cover back opening with the plate (kit WE49X22606) which can be purchased from haierappliances.com/parts or in Canada visit haiercanada.ca/parts. It may also be obtained from a local service provider. Place dryer in final location.


NEVER LEAVE THE BACK OPENING WITHOUT THE PLATE.

22

# **FINAL SETUP**


### 1 LEVEL THE DRYER

Stand the dryer upright near the final location and adjust the four leveling legs at the corners to ensure that the dryer is level from side to side and front to rear.




# 2 PLUG DRYER IN

**NOTE:** Stacking installations may require a power cord up to 6 feet in length.



### **3 DRYER START-UP**

Press and hold the power button.



**NOTE:** If the dryer has been exposed to temperatures below freezing for an extended period of time, allow it to warm up before pressing **Power**. Otherwise, the display will not come on.

The dryer is now ready for use.

# **▲WARNING** → Electrical Shock Hazard

Disconnect power supply before servicing.

Replace all parts and panels before operating.

Failure to do so can result in death or electrical shock.

# STACKING THE WASHER AND DRYER (if desired)

If you are planning to stack the washer and dryer, order Stacking Kit number GFA24KITL to be used for this dryer. Kit sold separately.

# **BEFORE YOU BEGIN**

Read these instructions completely and carefully.


- IMPORTANT Save these instructions for local electrical inspector's use.
- IMPORTANT Observe all governing codes and ordinances.
- Note to Installer Be sure to leave these instructions with the Consumer.
- Note to Consumer Keep these instructions for future reference.
- Service **must** be performed by a qualified installer.
- Do not allow children on or in the appliance. Close supervision of children is necessary when the appliance is used near children.
- Proper installation is the responsibility of the installer.

### HAIER APPLIANCES STACK KIT

Visit our website at haierappliances.com/parts or in Canada visit haiercanada.ca/parts.

**Part Number** Accessory **GFA24KITL** Complete Stack Kit

# KIT CONTENTS (HAIER APPLIANCES KIT # GFA24KITL)



### **TOOLS YOU WILL NEED**

■ Phillips screwdriver 







### REQUIREMENTS FOR ALCOVE OR **CLOSET INSTALLATION**



Keep flammable materials and vapors, such as gasoline, away from dryer.

Place dryer at least 18" (46 cm) above the floor for a garage installation.

Failure to do so can result in death, explosion, or fire.

- The dryer MUST be vented to the outdoors.
- Minimum clearance between dryer cabinet and adjacent walls or other surfaces is:

0" either side

1" front and rear

1" top

- The rear of the dryer should face a wall.
- Consideration must be given to provide adequate clearance for installation and service.
- Closet doors must be louvered or otherwise ventilated and have at least 60 square inches of open area. If the closet contains both a washer and a dryer, doors must contain a minimum of 120 square inches of open area.

**NOTE:** WHEN THE EXHAUST DUCT IS LOCATED AT THE REAR OF THE DRYER, THE CONFIGURATION OF THE **DUCTING MAY REQUIRE GREATER THAN 3" OF REAR** CLEARANCE.

### MINIMUM CLEARANCE OTHER THAN ALCOVE OR CLOSET INSTALLATION

Minimum clearance to combustible surfaces and for air opening are: 0" both sides, 1" rear and 1" top.

The rear of the dryer should face a wall.

Consideration must be given to provide adequate clearance for installation and service.

### INSTALLATION PREPARATION

Remove the packaging.

Flatten the product carton to use as a pad to lay the dryer down on its side. Continue using the carton to protect the finished floor in front of the installation location.


# INSTALLING THE STACK BRACKET KIT

### 1 INSTALL BRACKET TO WASHER

A. Remove washer top cap screw from the rear left. Align left bracket holes with top cap screw hole on rear left of the unit and replace screw.

NOTE: Leave screws loose so dryer hole alignment will be easier.

- **B.** Drive next screw through the bracket into the rear of the washer.
- **C.** Repeat the above steps with the right side.



# 2 INSTALL DRYER AND BRACKET ON **DRYER**

Disconnect power before installing. **▲WARNING** Failure to do so could result in serious injury or death.

# **AWARNING**




### - Excessive Weight Hazard

Failure to do so may result in back or other injury, or property damage.

- Use two or more people to install dryer.
- Avoid tipping and rupture of utility services.
- Dryer must be securely attached to the washer.
- DO NOT place the washer on top of the dryer.
- A. Lift the dryer on top of the washer. Protect the washer control panel with cardboard or other protection. Be sure to lift the dryer high enough to clear the washer control panel.
- B. Align the holes in the bracket with the holes in the back of the dryer. Using a Phillips screwdriver, attach the 2 #8 x 1/2" tapping screws.

# 2 INSTALL DRYER AND BRACKET ON DRYER (CONT.)


C. Tighten the dryer bracket screws; then tighten all stacking kit screws.



# 3 FINALIZE THE INSTALLATION

Do not push on the dryer once **ACAUTION** installed to top of the washer. Pushing on the dryer may result in pinched fingers.

- A. Refer to the washer Installation Instructions to complete the washer installation.
- B. Refer to the dryer Installation Instructions to complete the dryer installation.
- C. Carefully slide or walk the stacked washer and dryer into place. Use felt pads or other sliding device to assist moving and to protect flooring.




# **REVERSING THE DOOR SWING (Optional)**

### **IMPORTANT NOTES**

- Before you start, unplug the dryer from its electrical outlet.
- · Handle parts carefully to avoid scratching paint.
- Provide a non-scratching work surface for the doors.
- · Tools you will need: Phillips-head screwdriver.
- Once you begin, do not move the cabinet until doorswing reversal is completed.
- These instructions are for changing the hinges from the right side to the left side—if you ever want to switch them back to the right side, follow these same instructions and reverse all references to the left and right.


### 1 REMOVE THE DOOR ASSEMBLY

 Open the door. Remove the two screws holding the hinge/door assembly to the dryer. Carefully set the hinge/door assembly aside.




# 2 REMOVE, ROTATE AND REPLACE THE STRIKE PLATE

Remove the two screws holding the strike plate.
 Rotate it and install it on the opposite side.




# 3 REMOVE, ROTATE AND REPLACE THE INNER DOOR

 Remove the six screws securing the inner door to the outer door. Remove the inner door, rotate it 180° and reinstall it into the outer door using the same six screws



# 4 ROTATE AND REPLACE THE HINGE/ DOOR ASSEMBLY

 Rotate and replace the hinge/door assembly, on the opposite side, using the same two screws.



26

# **NOTES**

# TROUBLESHOOTING TIPS

Problem	Possible Cause	What To Do	
Dryer shakes or makes noise	Some shaking/noise is normal. Dryer may be sitting unevenly.	Move dryer to an even floor space, or adjust leveling legs as necessary until even.	
Clothes take too long to dry	Improper or obstructed ducting	Check the Installation Instructions to make sure the dryer venting is correct.	
		Make sure ducting is clean, free of kinks and unobstructed.	
		Check to see if outside wall damper operates easily.	
	Improper sorting	Separate heavy items from lightweight items (generally, a well-sorted washer load is a well-sorted dryer load).	
	Large loads of heavy fabrics (like beach towels)	Large, heavy fabrics contain more moisture and take longer to dry. Separate large, heavy fabrics into smaller loads to speed drying time.	
	Controls improperly set	Match control settings to the load you are drying.	
	Lint filter is full	Clean lint filter before every load.	
	Blown fuses or tripped circuit breaker	Replace fuses or reset circuit breakers. Since most dryers use 2 fuses/ breakers, make sure both are operating.	
	Overloading/combining loads	Do not put more than one washer load in the dryer at a time.	
	Underloading	If you are drying only one or two items, add a few items to ensure proper tumbling.	
The Dry dryness level was chosen	Load consists of a mixture of heavy and light fabrics	When combining heavy and light fabrics in a load, choose <b>More Dry.</b>	
but load is still damp	Lint filter is blocked	Inspect and clean lint filter.	
uamp	Dry Sensor is dirty	Clean the sensor with a moist cloth.	
Control buttons not responding	Controls accidentally put in service mode		
	Controls accidentally put in lock mode	Hold the <b>Lock Control</b> button for 3 seconds to unlock the dryer.	
	Controls performed an incorrect operation	Reset the in-house breaker.	
Dryer doesn't	Control panel is "asleep"	This is normal. Press <b>Power</b> to activate the control panel.	
start	Dryer is unplugged	Make sure the dryer plug is pushed completely into the outlet.	
	Fuse is blown/circuit breaker is tripped	Check the building's fuse/circuit breaker box and replace fuse or reset breaker. <b>NOTE:</b> Electric dryers use two fuses or breakers.	
	Dryer was accidentally paused when starting Delay Dry	If the light on the <b>Start/Pause</b> button is flashing, the dryer is paused. Press <b>Start/Pause</b> to restart the countdown.	
No numbers displayed during cycle, only lights	Dryer is continuously monitoring the amount of moisture in the clothes	This is normal. When the dryer senses a low level of moisture in the load, the dryer will display the dry time remaining.	

28

# TROUBLESHOOTING TIPS

Problem	Possible Causes	What To Do
Time Remaining jumped to a lower number	The estimated time may change when a smaller load than usual is drying	This is normal.
Cannot make a selection and the dryer beeps twice	The dryness Level, Temp or option that you are trying to select is incompatible with the chosen dry cycle	This is normal.
Dryer is running but 00 is displayed in Time Remaining	The Ext Tumble option was chosen	This is normal. During extended tumbling, the time remaining is not displayed. The extended tumbling option lasts approximately 60 minutes.
Clean Lint Filter (message)	Power button was activated	Press <b>Start/Pause</b> to begin a dry cycle and the message will disappear.
Dryer doesn't heat	Fuse is blown/circuit breaker is tripped; the dryer may tumble but not heat	Check the building's fuse/circuit breaker box and replace both fuses or reset both breakers. Your dryer may tumble if only one fuse is blown or one breaker tripped.
Inconsistent drying times	Type of load and drying conditions	The load size, types of fabric, wetness of clothes and the condition of the lint filter and/or air intake vent located on the front of the dryer will affect drying times.
	Type of load and drying conditions	The load size, types of fabric, wetness of clothes and the length and condition of the exhaust system will affect drying times.
Glow at the rear of the drum	Heaters behind the drum	This is normal. Under certain drying conditions and room ambient lighting, the glow of the heaters may be visible at the rear of the drum.
Clothes are still wet and dryer shut off after a short time	The door was opened mid- cycle. The load was then removed from the dryer and a new load put in without selecting a new cycle	A dry cycle must be reselected each time a new load is put in.
	Small load	When drying 3 items or less, choose <b>Quick Dry</b> or <b>Time Dry</b> .
	Load was already dry except for collars and waistbands	Choose <b>Quick Dry</b> or <b>Time Dry</b> to dry damp collars and waistbands. In the future, when drying a load with collars and waistbands, choose <b>More Dry</b> .
	Dryer is not level	Move dryer to an even floor space or adjust leveling legs as necessary until even.
Clothes are wrinkled	Overdrying	Select a shorter drying time. Remove items while they still hold a slight amount of moisture. Select a Less Dry or Damp setting.
	Letting items sit in dryer after cycle ends	Remove items when cycle ends and fold or hang immediately, or use the <b>Ext Tumble</b> option.
	Overloading	Separate large loads into smaller ones.

# TROUBLESHOOTING TIPS

Problem	Possible Causes	What To Do
Clothes shrink	Some fabrics will naturally	To avoid shrinkage, follow garment care labels exactly.
	shrink when washed. Others can be safely washed, but will	Some items may be pressed back into shape after drying.
	shrink in the dryer.	If you are concerned about shrinkage in a particular item, do not machine wash or tumble dry it.
Greasy spots on	Improper use of fabric softener	Follow directions on fabric softener package.
clothes	Drying dirty items with clean ones	Use your dryer to dry only clean items. Dirty items can stain clean items and the dryer.
	Clothes were not completely clean	Sometimes stains which cannot be seen when the clothes are wet appear after drying. Use proper washing procedures before drying.
Lint on clothes	Lint filter is full	Clean lint screen before each load.
	Improper sorting	Sort lint producers (like chenille) from lint collectors (like corduroy).
	Static electricity can attract lint	See suggestions in this section under <b>Static occurs</b> .
	Overloading	Separate large loads into smaller ones.
	Paper, tissue, etc., left in pockets	Empty all pockets before laundering clothes.
Static occurs	No fabric softener was used	Try a fabric softener.
		Bounce <sup>®</sup> Fabric Conditioner Dryer Sheets have been approved for use in all Haier Appliances dryers when used in accordance with the manufacturer's instructions.
	Overdrying	Try a fabric softener. Adjust setting to <b>Less Dry</b> or <b>Damp</b> .
	Synthetics, permanent press and blends can cause static	Try a fabric softener.
Collars and waistbands still wet at end of cycle	The dryness monitor senses that the body of the clothes is dry	Choose <b>Quick Dry</b> or <b>Time Dry</b> to dry damp collars and waistbands. In the future, when drying a load with collars and waistbands, choose <b>More Dry</b> .
Slight variation in metallic color	This is normal	Due to the metallic properties of paint used for this unique product, slight variations of color may occur due to viewing angles and lighting conditions.
Dryer continues to tumble after display says Complete	Ext Tumble was selected	Ensure <b>Ext Tumble</b> option is not selected.

# LIMITED WARRANTY

### haierappliances.com

All warranty service is provided by our Factory Service Centers, or an authorized Customer Care® technician. To schedule service online, visit us at **haierappliances.com/support/schedule-service** or in Canada **haiercanada.ca/service**. Please have your serial number and your model number available when contacting us for service.

Servicing your appliance may require the use of the onboard data port for diagnostics. This gives a Haier Appliances factory service technician the ability to quickly diagnose any issues with your appliance and helps Haier Appliances improve its products by providing Haier Appliances with information on your appliance. If you do not want your appliance data to be sent to Haier Appliances, please advise your technician not to submit the data to Haier Appliances at the time of service.

For the period of	Haier Appliances will replace	
One year	Any part of the washer which fails due to a defect in materials or workmanship. During this limited	
From date of the	one-year warranty, Haier Appliances will provide, free of charge, all labor and in-home service to	
original purchase	replace the defective part.	

### What Haier Appliances will not cover:

- Service trips to your home to teach you how to use the product.
- Improper installation, delivery or maintenance.
- Failure of the product if it is abused, misused, or used for other than the intended purpose or used commercially.
- Replacement of house fuses or resetting of circuit breakers.
- Products which are not defective or broken, or which are working as described in the Owner's Manual.
- Damage to the product caused by accident, fire, floods or acts of God.
- Incidental or consequential damage caused by possible defects with this appliance.
- Defects or damage due to operation in freezing temperatures.
- Damage caused after delivery.
- Product not accessible to provide required service.
- Cleaning of condenser to restore product drying performance.

### **EXCLUSION OF IMPLIED WARRANTIES**

Your sole and exclusive remedy is product repair as provided in this Limited Warranty. Any implied warranties, including the implied warranties of merchantability or fitness for a particular purpose, are limited to one year or the shortest period allowed by law.

### In the United States:

This limited warranty is extended to the original purchaser and any succeeding owner for products purchased for home use within the USA. If the product is located in an area where service by a Haier Appliances Authorized Servicer is not available, you may be responsible for a trip charge or you may be required to bring the product to an Authorized Haier Appliances Service location for service. In Alaska, the limited warranty excludes the cost of shipping or service calls to your home.

Some states do not allow the exclusion or limitation of incidental or consequential damages. This limited warranty gives you specific legal rights, and you may also have other rights which vary from state to state. To know what your legal rights are, consult your local or state consumer affairs office or your state's Attorney General.

Warrantor: Haier Appliances, Louisville, KY 40225

#### In Canada:

This limited warranty is extended to the original purchaser and any succeeding owner for products purchased in Canada for home use within Canada. If the product is located in an area where service by a Haier Appliances Authorized Servicer is not available, you may be responsible for a trip charge or you may be required to bring the product to an Authorized Haier Appliances Service location.

Some provinces do not allow the exclusion or limitation of incidental or consequential damages. This limited warranty gives you specific legal rights, and you may also have other rights which vary from province to province. To know what your legal rights are, consult your local or provincial consumer affairs office.

Warrantor: MC Commercial Inc., Burlington, ON, L7R 5B6

### **CONSUMER SUPPORT**

### **Haier Appliances Website**

Have a question or need assistance with your appliance? Try the Haier Appliances Website 24 hours a day, any day of the year! You can also shop for more great Haier Appliances products and take advantage of all our on-line support services designed for your convenience. In the US: haierappliances.com

### **Register Your Appliance**

Register your new appliance on-line at your convenience! Timely product registration will allow for enhanced communication and prompt service under the terms of your warranty, should the need arise. You may also mail in the pre-printed registration card included in the packing material. In the US: haierappliances.com/support/register

In Canada:prodsupport.mabe.ca/crm/Products/ProductRegistration.aspx

#### Schedule Service

Expert Haier Appliances repair service is only one step away from your door. Get on-line and schedule your service at your convenience any day of the year. In the US: haierappliances.com/support/schedule-service.

In Canada: haiercanada.ca/service

### **Remote Connectivity**

For assistance with wireless network connectivity (for models with remote enable), visit our website in the US at haierappliances.com

### **Parts and Accessories**

Individuals qualified to service their own appliances can have parts or accessories sent directly to their homes (VISA, MasterCard and Discover cards are accepted).

In the US: haierappliances.com/parts

In Canada: haiercanada.ca/parts

Instructions contained in this manual cover procedures to be performed by any user. Other servicing generally should be referred to qualified service personnel. Caution must be exercised, since improper servicing may cause unsafe operation.

### **Contact Us**

If you are not satisfied with the service you receive from Haier Appliances, contact us on our website at **haierappliances.com/support/contact-us** with all the details including your phone number, or write to:

In the US: Haier Appliances, Consumer Relations | PO Box 1780 | Rapid City, SD 57709

In Canada: haiercanada.ca/contact-us